

GSM BSS 08B


Trening programi




GSM BSS 08B

Razlikovni trening

GSM RAN BSS 08, Razlikovni trening




APG 43, Razlike




GSM BSS 08B

Osnove


GSM, Osnove sustava



IP, Osnove




IP GSM Pristupna radio mreža




GSM BSS 08B

Terensko održavanje


GSM BSS 08 RBS 2x06, Terensko održavanje




GSM BSS 08 RBS 2x16, Terensko održavanje



GSM BSS 08 RBS 2111, Terensko održavanje



GSM BSS 08 RBS 2409, Terensko održavanje




SIU, Terensko održavanje

GSM, Osnove mreže
GSM BSS 08 RBS 2x06, Održavanje, LZU1087123
ili
GSM BSS 08 RBS 2X16, Održavanje, LZU1087125
ili
GSM BSS 08 RBS 2X16, Održavanje, razlike, LZU1087124
ili
GSM BSS 08 RBS 2111, Primjena i održavanje, LZU1087127

SIU, Terensko održavanje,
(1 dan ILT) LZU1087281




GSM BSC, Održavanje




GSM BSS 08B

Eksploatacija Mreže


GSM RAN, Nadzor Mreže




GSM BSS 08 RBS, Konfiguracija



APG 40, Eksploatacija i Konfiguracija



APG 43, Eksploatacija i konfiguracija



APZ 212 55, Eksploatacija


GSM AXE, Eksploatacija, LZU 108 5024/2 ili
AXE, Eksploatacija i konfiguracija, LZU 108 6145




APZ 212 55, Eksploatacija i održavanje,
(3 dana ILT) LZU1086847




GSM BSC, Eksploatacija i konfiguracija




GSM BSS 08, GPRS/EDGE Signalizacija




OSS-RC 5, Uvod




AXE, Eksploatacija uz korištenje OSS-RC 5




GSM RAN BSS 08, Trening za pojedine značajke



GSM FEMTO Ćelijsko rješenje, konfiguracija




SIU, Eksploatacija i konfiguracija




GSM BSS 08B

Razvoj mreže


GSM BSS 08, Dizajn mreže



GSM Radio mreža, statistika



GSM BSS 08, Optimiziranje radio mreže



GSM BSS 08 / WCDMA RAN P7, Optimizacija

